



RIO GRANDE SOUTHERN RAILROAD.

EMPLOYEES' TIME TABLE

No. 29.

To Take Effect at 12:01 O'clock A. M. June, 26, 1898.

This Time Table Is for the Guidance of Employes Only,

And is not intended for the Information of the Public, or as an

Advertisement of any Train.

The Company reserves the right to vary from it at pleasure.

STANDARD TIME, 105th MERIDIAN.

FIRST DISTRICT.—Ridgway and Rico.

SOUTHWARD.				MILES FROM RIDGWAY.	TIME TABLE No. 29.		MILES FROM RICO.	NORTHWARD.				CAR CAPACITY OF SIDINGS, WYES, WATER & COAL.
2d CLASS.		1st CLASS.			STATIONS AND SIDINGS			1st CLASS.		2d CLASS.		
9 FREIGHT.		7 PASS'GR.	5 PASS'GR.					6 PASS'GR.	8 PASS'GR.		10 FREIGHT.	
Lv. Daily except Sunday. A. M.		Lv. Daily	Lv. Daily		Ar. Daily P. M.	Ar. Daily A. M.		Ar. Daily except Sunday. P. M.				
8.35		2.30	8.00					4.25	x 118 \$			
f 8.55		f 2.43	f 8.13	5.2	Ds	66.2	f 4.30	f 11.15				
f 9.23		f 3.05	f 8.33	9.7		61.0	f 4.17	f 11.02	f 4.06	33		
9.50 9.58		s 3.25	s 8.50	13.3		56.6	f 4.00	f 10.45	f 3.43	11		
f 10.19		f 3.35	f 9.00	16.1		52.9	s 3.45	s 10.30	3.25 3.15	Y 52		
f 10.50		f 3.55	f 9.20	22.2		50.1	f 3.35	f 10.19	f 2.52	12		
s 11.15		s 4.10	s 9.35	26.0	D	44.0	f 3.13	f 9.52	f 2.10	O 25		
f 11.28		f 4.18	f 9.42	29.1		39.6	s 2.58	s 9.35	s 1.45	Y 42		
f 11.35		s 4.21	s 9.45	30.2	D	37.1	f 2.50	f 9.27	f 1.33	28		
f 11.47		f 4.30	f 9.52	32.6		36.0	f 2.46	s 9.23	f 1.28	7		
12.15 12.45		4.45 4.55	10.05 10.10	37.8	D	33.6	f 2.38	f 9.15	f 1.17	27		
f 1.10		f 5.11	f 10.23	41.0	□ (Bridge 43 A)	28.4	2.23 2.18	9.00 8.50	12.55 12.30	Y 75		
s 1.53		s 5.30	s 10.38	45.0	D	25.2	f 2.06	f 8.38	f 12.12	O 9		
f 2.10		f 5.40	f 10.48	46.7		21.2	s 1.53	s 8.23	s 11.52	19		
f 2.27		f 5.52	f 10.58	49.1		19.5	f 1.43	f 8.13	f 11.40	22		
2.50 2.55		s 6.10	s 11.10	52.6	□	17.1	f 1.35	f 8.03	f 11.27	O 28		
f 3.40		f 6.35	f 11.34	60.5		13.6	s 1.23	s 7.50	11.10 11.00	Y 28		
f 3.55		f 6.42	f 11.41	63.6		5.7	f 12.53	f 7.20	f 10.00	O 24		
4.15		6.50	11.50	66.2	D	2.6	f 12.43	f 7.10	f 9.43	31		
P. M. Ar. Daily Ex. Sun.		P. M. Arrive Daily.	A. M. Arrive Daily			12.33	7.00		9.25	V O ● \$ 144		
(7.40)		(4.20)	(3.50)				P. M. Leave Daily	A. M. Leave Daily	A. M. Lv. Daily except Sunday.			

Water tanks are located near mile posts 10 and 35.

No Train or Engine will leave Ridgway or Rico, without special orders or clearance ticket.

SPECIAL RULES AND REGULATIONS.

RIGHTS OF TRAINS—North-Bound Trains have absolute right of track over South-Bound Trains of the same or inferior class.

1. TRAIN WORK.—Trains must be made up systematically in station order, which order will be preserved in taking or leaving cars. In loading freight, it must, as far as practicable, be consolidated in full carloads, and occupy the least number of cars required, irrespective of other cars having to go empty in the same direction. Conductors must observe the above in loading local freight. Agents at way stations must hold small lots of freight to load on trains, instead of loading in cars at station. Agents at terminals will transfer and consolidate the contents of lightly loaded cars. Not more than two engines must be coupled to one passenger train. If more power is required, trains must be divided.

2. SPEED OF TRAINS.—Trains must not exceed six miles per hour within the corporate limits of towns or cities, and all trains, when approaching stations where switch engines are employed, must be under full control, expecting to find main line blocked. No train will exceed schedule time on grades exceeding 100 feet per mile. Special passenger trains and light engines must not exceed the schedule time of first-class trains, nor extra freight and work trains that of second class trains.

All trains will reduce speed to six miles per hour over high bridges, eight miles south of Ridgway, and at Haskell's spur; also while passing

through the town of Placerville. All second class and irregular trains will reduce speed to six miles per hour in yard limits at Vance Junction and Rico. All trains will reduce speed to eight miles per hour over bridges between San Bernardo and Ames.

All engines must blow the whistle and ring the bell frequently while running between Fall Creek and South Fork.

3. Rio Grande Southern employes will be governed by General Rules and Regulations in effect on the Denver and Rio Grande Railroad.

4. AIR BRAKES.—The air-hose, when not coupled between cars, must be coupled to dummy coupling provided for that purpose. (See Question No. 1, Air-Brake Instructions.) Straight air will be used on Mixed and Freight Trains. Air-Brakes must be tested on trains before leaving terminal stations, as required by Air-Brake Instructions. When double-headers are run, the air must be coupled to both engines, and forward engineman must operate the air-brake. Pushing Engines must always have air-brake coupled.

5. Passengers will not be carried on freight trains.

A. S. MELDRUM, TRAIN MASTER. W. D. LEE, GENERAL SUPT. E. T. JEFFERY, PRESIDENT.

SECOND DISTRICT--Rico and Durango.

SOUTHWARD.				MILES FROM RIDGWAY.	TIME TABLE No. 29.		MILES FROM DURANGO.	NORTHWARD.				CAR CAPACITY OF SIDINGS, WYES, WATER & COAL.
2 ^D CLASS.		1 ST CLASS.			STATIONS AND SIDINGS			1 ST CLASS.		2 ^D CLASS.		
11 FREIGHT.		5 PASS'GER.						6 PASS'GER.		12 FREIGHT.		
Lv. Daily Ex. Sun. A. M.		Lv. Daily P. M.				Ar. Daily P. M.		Ar. Daily Ex. Sun. P. M.				
9.45		12.15		66.2	D	RICO	Ro	95.9	12.08		4.05	Y ● ○ 144 ⁵⁵
f 10.02		f 12.25		70.2		4.0 MONTELORES		91.9	f 11.57		f 3.40	22
f 10.20		f 12.35		74.5		4.3 KINGS		87.6	f 11.45		f 3.15	24
f 10.45		f 12.50		80.2		5.7 BEAR CREEK		81.9	f 11.28		f 2.45	29
f 11.14		f 1.04		85.9		5.7 MULLDOON	Rd	78.2	f 11.14		f 2.15	35
f 11.32		f 1.15		90.2		4.3 RAYMOND		71.9	f 11.08		f 1.52	39
f 11.56		f 1.27		96.3		6.1 STAPLETON		65.8	f 10.49		f 1.27	40
12.20 12.35		s 1.40		102.3	D	6.0 DOLORES	Dj	59.8	s 10.35		f 12.55 12.35	97
1.20		f 2.05		111.8		9.5 GLENCOE	Ge	50.3	f 10.10		f 11.55	Y 29
s 1.40		f 2.15		115.6		3.3 MILWOOD		46.5	f 10.00		s 11.35	41
2.10 2.15		s 2.37		122.1	D	6.5 MANCOS	Mx	40.0	s 9.40		11.00 10.55	Yo 45
f 2.35		f 2.48		125.3		3.2 MENEFFEE		36.8	f 9.29		f 10.42	18
f 3.19		f 3.19		132.9		7.6 MESA	Ma	29.2	f 9.05		f 10.07	35
f 3.45		f 3.33		136.5		3.6 DIX		25.6	f 8.53		f 9.52	19
s 4.10		f 3.48		141.2		4.7 CIMA		20.9	f 8.35		s 9.30	33
s 4.40		s 4.03		145.6	D	4.4 HESPERUS	Ht	16.5	s 8.21		s 9.05	○ 44
s 4.55		f 4.10		147.0		1.4 UTE JUNCTION		15.1	f 8.15		s 8.50	Y ● 37
f 5.25		f 4.30		154.2		7.2 PINE RIDGE		7.9	f 7.54		f 8.10	34
s 5.45		f 4.40		157.1		2.9 PORTER		5.0	f 7.47		s 7.47	Yo 149
6.20		5.00		162.1	D ‡	5.0 DURANGO	Dg	7.30			7.00	● ○ X 302 ⁵⁵
P. M. Ar. Daily Ex. Sun.		P. M. Ar. Daily				95.9		A. M. Lv. Daily			A. M. Lv. Daily Ex. Sun.	

(8.35) (4.45) (4.38) (9.05)
 No Train or Engine will leave Rico or Durango without special order or clearance ticket. All trains will leave a registering ticket in box at Ute Junction.
 All Trains and Engines must come to full stop before passing switch to Coke Ovens at Durango, and sharp look-out kept for Switch Engines in Durango yard.
 Water Tanks are located at mile posts 78, 87 and 131. All trains must be under full control passing yard limit boards at Mancos and Porter.

TELLURIDE BRANCH.

SOUTHWARD.				MILES FROM RIDGWAY.	TIME TABLE No. 29.		MILES FROM PANDORA.	NORTHWARD.				CAR CAPACITY OF SIDINGS, WYES, WATER & COAL.
1 ST CLASS.					STATIONS AND SIDINGS			1 ST CLASS.				
29 MIXED.	27 MIXED.	25 MIXED.						26 MIXED.	28 MIXED.	30 MIXED.		
Lv. Daily P. M.	Lv. Daily P. M.	Lv. Daily A. M.				Ar. Daily P. M.	Ar. Daily A. M.	Ar. Daily P. M.				
2.25	4.55	10.10	37.8	D	VANCE JUNCTION	Mi	9.8	2.15	8.45	4.40	Y 75	
f 2.45	f 5.15	f 10.30	41.7		3.9 KEYSTONE		5.7	f 1.55	f 8.25	f 4.20	10	
f 2.50	f 5.20	f 10.35	43.7		2.0 SAN MIGUEL		3.7	f 1.50	f 8.20	f 4.15	25	
2.55	5.25	10.40	45.1	D	1.4 TELLURIDE	Do	2.3	1.45	8.15	4.10	● ○ Y 109	
			47.4		2.3 PANDORA						36	
P. M. Ar. Daily	P. M. Ar. Daily	A. M. Ar. Daily			9.6		P. M. Lv. Daily	A. M. Lv. Daily	P. M. Lv. Daily			

(0.30) (0.30) (0.30)
 No Train or Engine will leave Telluride without special order or clearance ticket.

ADDITIONAL SPURS NOT SHOWN IN REGULAR TIME TABLES

	LOCATION			NAMES	CAR CAPACITY	SWITCH CONNECTIONS
	DISTRICT	MILE				
	First	3.0		JAY'S SPUR	14.	North End
	"	6.9		TIE SPUR	3.	North End
	"	17.1		SAM'S SPUR	7.	North End
	"	21.5		HASKELL'S SPUR	10.	"
	"	36.4		SOUTH FORK	35.	South End
	"	43.9		BUTTERFLY	15.	South End
	"	50.8		SUFFOLK	3.	Disconnected
	"	63.8		RICE'S SPUR	4.	North End
	"	55.7		GALLAGHER'S SPUR	12.	North End
	"	59.3		LONG'S SPUR	5.	South End
	"	64.7		WINKFIELD'S SPUR	8.	North End
	Telluride Br.	38.6		ILLIUM	22.	Both Ends
	Second	100.3		RUST'S SPUR	14.	North End
	"	109.4		LOST CANON	40.	Both Ends
	"	112.3		BARNES	48.	South End
	"	116.3		GRADENS'	15.	"
	"	124.5		BUCKLEY'S	4.	North End
	"	129.2		BRAYTON	7.	"
	"	145.9		CUNNINGHAMS	14.	South End
	"	143.8		FT. LEWIS	7.	Both Ends
	"	154.9		FRANKS	8.	North End
	"	160.6		BELL'S SPUR	37.	South End

EXPLANATION OF CHARACTERS.

Letters at right of station names indicate telegraph call. Figures under each district and train indicate mileage of district and time used by trains in passing over the same.

- | | | |
|------------------------------------|--------------------|---------------------------------|
| N—Day and Night Telegraph Offices. | X—Turn Table. | ○—Telegraph Box. |
| s—Regular Stop. | ●—Coal. | ○—Water. |
| Y—Wye. | ⊙—Stop on Signals. | ⊖—Stop for Meals. |
| B—Bulletins. | ⊕—Standard Clock. | D—Day (only) Telegraph Offices. |

REGISTERING STATIONS

B. Ridgway Placerville B. Vance Junction B. Telluride B. Rico Dolores	Mancos B. Durango
--	----------------------