

The Rio Grande Southern Railroad Company

EMPLOYEES' TIME TABLE

To Take Effect 12:01 A. M., Sunday, June 18, 1911.

STANDARD TIME 105th MERIDIAN

This Time Table is for the guidance of employees only, and is not intended for the information of the public, or as an advertisement of any train. The Company reserves the right to vary from it at pleasure.

H. W. CLARKE,
Second Vice-President and General Manager.

W. D. LEE,
General Superintendent.

C. D. WOLFINGER,
Superintendent.

FIRST DISTRICT - RIDGWAY AND RICO

SOUTHWARD

NORTHWARD

SECOND CLASS

FIRST CLASS

Time Table No. 57
June 18, 1911
STATIONS AND SIDINGS

FIRST CLASS

SECOND CLASS

FREIGHT	PASSGR	MIXED	MILES FROM RIDGWAY	STATIONS AND SIDINGS	MILES FROM RICO	MIXED	PASSGR	FREIGHT	Car Capacity of Passing Tracks and Location of Scales, Water, Fuel and Turning Stations.
9.20	4.20	5.00	5.2	RIDGWAY	66.2	6.30	10.30	3.25	Y O ●
9.45	4.35	5.2	5.2	HAGENS	61.0	6.15	10.15	3.00	Y O ●
10.06	4.46	5.3	7.3	DETI	58.9	6.30	10.06	2.46	33
10.30	4.58	5.3	9.6	VALLEY VIEW	56.6	6.45	9.55	2.30	11
11.05	5.20	5.3	13.3	DALLAS DIVIDE	52.9	6.38	9.38	2.10	Y ● 52
11.27	5.30	5.3	16.1	LHOPLAND CREEK	50.1	6.22	9.22	1.85	12
11.59	5.52	5.3	22.2	BROWN	44.0	6.58	8.58	1.25	Y O ● 25
12.25	6.08	5.3	26.6	PLACERVILLE	39.6	8.41	8.41	1.15	Y ● 42
12.55	6.17	5.3	29.1	FALL CREEK	37.1	8.29	8.29	1.40	7
1.08	6.21	5.3	30.2	SAW PIT	36.0	8.25	8.25	1.34	7
1.15	6.31	5.3	32.6	WILSON	33.6	8.18	8.18	1.21	27
1.32	6.46	5.3	35.4	RICO	29.8	8.04	8.04	1.00	15
2.00	6.50	5.3	37.8	VANCE JUNCTION	28.4	8.00	8.00	1.50	Y ● 75
2.10	7.35	5.3	41.3	AXES	24.9	5.33	8.07	10.07	5
2.50	8.15	5.3	45.0	OPHIR	21.2	5.18	8.43	9.43	19
3.25	8.23	5.3	46.7	MATTHEBORN	19.5	5.10	8.30	9.30	22
3.40	8.35	5.3	49.1	TROUD LAKE	17.1	4.57	8.15	9.15	28
4.05	8.50	5.3	52.6	LIZARD HEAD	13.6	4.43	8.55	8.55	Y ● 28
4.35	8.52	5.3	55.7	GALLAGHERS	10.5	4.27	8.28	8.28	12
4.58	9.05	5.3	59.5	CORE OVENS	5.7	4.13	7.40	7.40	24
5.25	9.20	5.3	63.6	BURNS	2.6	4.03	7.18	7.18	31
5.45	9.30	5.3	66.2	RICO		3.53	7.00	7.00	Y O ● 31
6.00	9.40	5.3							144

Water tanks are located near mile posts 10 and 35. No Train or Engine will leave Ridgway or Rico without clearance. Noel's Crossing, Mile Post 14.6 is a flag stop.

TELLURIDE BRANCH

Time Table No. 57
June 18, 1911

STATIONS AND SIDINGS	MILES FROM RIDGWAY	MILES FROM TELLURIDE	FIRST CLASS	SECOND CLASS	Car Capacity of Passing Tracks and Location of Scales, Water, Fuel and Wyes
VANCE JUNCTION	37.8	7.3	7.35	8.00	Y ● 75
ANDERSON	38.6	6.5	7.28	7.56	Y ● 22
KEYSTONE	41.7	3.4	7.10	7.40	10
SAN MIGUEL	43.7	1.4	7.04	7.34	25
TELLURIDE	45.1		7.00	7.30	Y O ● 109

No Train or Engine will leave Telluride without clearance.

SECOND DISTRICT-RICO AND DURANGO

SOUTHWARD					NORTHWARD						
SECOND CLASS		FIRST CLASS		Time Table No. 57 June 18, 1911					SECOND CLASS		
11 FREIGHT Leave Daily A. M.		5 MIXED Leave Daily A. M.		STATIONS AND SIDINGS		MILES FROM DURANGO					
MILES FROM RIDGWAY		MILES FROM DURANGO		6 MIXED Arrive Daily P. M.		FIRST CLASS		12 FREIGHT Arrive Daily P. M.		SECOND CLASS	
7.20		9.45		RICO		95.9		3.45		5.00	
7.39		9.58		MONTEPELERS		91.9		3.30		4.35	
7.58		10.12		KINGS		87.6		3.19		4.10	
8.25		10.31		BEAR CREEK		81.9		3.00		3.39	
8.50		10.48		MULDOON		76.2		2.43		3.04	
9.10		11.01		RAYMOND		71.9		2.30		2.41	
9.37		11.18		STAPLETON		65.8		2.12		2.12	
10.05		11.35		DOLORES		59.8		1.35		1.45	
10.15		12.00		LOST CANON		58.7		1.32		1.20	
10.20		12.04		GLENCOE		50.3		1.05		1.15	
11.15		12.35		MILLWOOD		46.5		12.30		12.35	
11.45		12.50		MANCOS		39.6		12.20		12.10	
12.20		1.17		MENEFEE		36.8		12.09		11.45	
12.45		1.31		GRADY		29.2		11.39		11.00	
1.05		2.08		DIX		25.6		11.25		10.25	
2.08		2.22		GIMA		20.9		11.10		10.08	
2.38		2.40		HESPERUS		16.5		11.08		9.50	
3.00		2.42		UTE JUNCTION		15.1		10.48		9.30	
3.30		2.59		PINE RIDGE		15.1		10.42		9.00	
3.55		3.04		POPPER		7.9		10.11		8.50	
4.35		3.28		FRANKLIN		5.0		9.57		8.00	
4.52		3.38		DURANGO		2.8		9.47		7.40	
5.06		3.44		95.9		9.35		7.20		7.20	
5.20		3.55		162.1		7.00		7.00		7.00	
(10.00)		(6.10)		(6.10)		(6.10)		(6.10)		(10.00)	

No Train or Engine will leave Rico or Durango without clearance. All trains will leave a registering ticket in box at Franklin. All Trains and Engines must come to full stop before passing switch to
Coke Ovens at Durango, and sharp look-out kept for Switch Engines in Durango yard. Water Tanks are located at mile posts 78, 87 and 131. All trains must be under full control passing yard limit boards at
Doloris, Glencoe, Mancos and Durango.

EXPLANATION OF CHARACTERS

Letters at right of station names indicate telegraph call. Figures under each district and train indicate mileage of district and time used by trains in passing over the same.

- N—Day and Night Telegraph Offices
- S—Regular Stop
- Y—Wye
- B—Bulletins
- X—Turn Table
- Coal
- †—Stop on Signals
- Telegraph Box
- §—Scales
- ‡—Standard Clock
- Water
- ‡—Stop for Meals
- D—Day (only) Telegraph Offices

ENGINE RATING IN TONS OF 2,000 POUNDS

FIRST DISTRICT		SECOND DISTRICT			
60 Class Engines Freight	47 Class Engines Mixed	60 Class Engines Mixed	45 1/2 class Engines Mixed	60 Class Engines Freight	47 Class Engines Mixed
85	60	60	80	215	160
85	60	60	115	135	85
105	120	80	80	135	85
105	80	80	80	135	85
112	80	80	80	135	85
112	80	80	80	135	85
112	80	80	80	135	85
112	80	80	80	215	155
112	80	80	80	85	60

Car Capacity of Passing Tracks and Location of Scales, Water, Fuel and Turning Stations.

ADDITIONAL SPURS Not Shown in Regular Time Table

LOCATION	NAMES	CAR CAPACITY	SWITCH CONNECTIONS
DISTRICT			
MILE			
FIRST	JAY'S	7.	NORTH END
"	NOEL'S	8.	SOUTH END
"	SAM'S	10.	SOUTH END
"	LEONARD	11.	NORTH END
"	VANADIUM	11.	SOUTH END
"	LIME	3.	SOUTH END
"	BUTTERFLY	16.	SOUTH END
"	SNOW	4.	SOUTH END
"	MURPHY	6.	DISCONTINUED
"	WINKERFIELD	8.	NORTH END
"	ILLUM	8.	NORTH END
TELLURIDE BR.	PANDORA	1.	NORTH END
"	47.4		
SECOND	LONGS	6.	SOUTH END
"	183.36		NORTH END
"	124.57		DISCONTINUED
"	129.2		NORTH END
"	141.9		SOUTH END
"	190.6		SOUTH END

REGISTERING STATIONS

B. Ridgeway	Mancos
Placerville	B. Durango
B. Vance Junction	
B. Telluride	
B. Rico	
Dolores	

LOCAL SURGEONS

J. W. O'CONNOR, Chief Surgeon, Denver.
G. N. TOWERS, Ridgeway.
E. HADLEY, Telluride.
U. L. ALBERS, Rico.
R. B. CARROLL, Dolores.
L. H. CLARK, Mancos.
H. L. TURBELL, Durango.

SPEED TABLE

SPEED PER HOUR	TIME OF PERFORMANCE						SPEED PER HOUR	TIME OF PERFORMANCE						
	1/4 MILE	1/2 MILE	3/4 MILE	1 MILE	1 1/4 MILE	1 1/2 MILE		1/4 MILE	1/2 MILE	3/4 MILE	1 MILE	1 1/4 MILE	1 1/2 MILE	
1	M.	S.	M.	S.	M.	S.	M.	S.	M.	S.	M.	S.		
2	15	0	30	0	60	0	31	0	29	0	58	0		
3	10	0	20	0	40	0	22	0	22	0	46	0		
4	7	30	10	0	20	0	16	0	16	0	33	0		
5	5	0	10	0	20	0	13	0	13	0	27	0		
6	4	45	0	30	15	0	11	0	11	0	23	0		
7	3	0	6	0	12	0	9	0	9	0	19	0		
8	2	30	0	6	0	10	0	8	0	8	0	17	0	
9	2	0	3	45	0	9	0	7	0	7	0	15	0	
10	1	40	0	2	0	6	0	6	0	6	0	14	0	
11	1	0	3	30	0	5	0	5	0	5	0	13	0	
12	1	15	0	2	45	0	4	0	4	0	4	0	12	0
13	1	0	1	0	18	0	4	0	3	0	4	0	11	0
14	1	0	0	0	16	0	4	0	3	0	4	0	10	0
15	1	0	0	0	15	0	4	0	3	0	4	0	10	0
16	1	0	0	0	14	0	4	0	3	0	4	0	10	0
17	1	0	0	0	13	0	4	0	3	0	4	0	10	0
18	1	0	0	0	12	0	4	0	3	0	4	0	10	0
19	1	0	0	0	11	0	4	0	3	0	4	0	10	0
20	1	0	0	0	10	0	4	0	3	0	4	0	10	0
21	1	0	0	0	9	0	4	0	3	0	4	0	10	0
22	1	0	0	0	8	0	4	0	3	0	4	0	10	0
23	1	0	0	0	7	0	4	0	3	0	4	0	10	0
24	1	0	0	0	6	0	4	0	3	0	4	0	10	0
25	1	0	0	0	5	0	4	0	3	0	4	0	10	0
26	1	0	0	0	4	0	4	0	3	0	4	0	10	0
27	1	0	0	0	3	0	4	0	3	0	4	0	10	0
28	1	0	0	0	2	0	4	0	3	0	4	0	10	0
29	1	0	0	0	1	0	4	0	3	0	4	0	10	0
30	1	0	0	0	0	0	4	0	3	0	4	0	10	0

SPECIAL RULES AND REGULATIONS.

RIGHTS OF TRAINS—North-Bound Trains have absolute right of track over South-Bound Trains of the same or inferior class.

1. TRAIN WORK.—Trains must be made up systematically in station order, which order will be preserved in taking or leaving cars. In loading freight, it must as far as practicable, be consolidated in the order in which the cars are required. Conductors must observe the above rule for empty freight cars. Freight cars must be loaded in the order of freight to load on trains. Instead of loading in cars at station, Agents at terminals will transfer and consolidate the contents of lightly loaded cars.

2. SPEED OF TRAINS.—Trains must not exceed six miles per hour within the corporate limits of towns or cities, and all trains, when approaching stations where switch engines are employed, must be under full control, expecting to find main line blocked. No train will exceed schedule time on grades exceeding 100 feet per mile. Special passenger trains and light engines must not exceed the schedule time of first-class trains, nor extra freight and work trains that of second-class trains.

3. SPEED OF TRAINS.—Trains must not exceed six miles per hour over bridge at Lenoir, and while passing through the town of Placerville. All second-class and irregular trains will reduce speed to six miles per hour in yard limits at Vance Junction and Rico. All trains will reduce speed to eight miles per hour over bridges between Matthehorn and Arnes.

4. Members of train crews must look over the air brakes, as well as general condition of the train before leaving Dallas Divide, Telluride, Lizard Head, Millwood and Cina and put same in safe condition before descending the grade. During the test of air brakes at these stations, and while the air is applied, brakemen will turn up all retaining valves to ascertain their condition, and any found out of order, or any other defect in the air brakes, which can not be promptly repaired, the usual Air Brake Defect Card will be applied to the main beam of the car, stating nature of defect. Piston travel must be adjusted to four (4) inches on freight cars and five (5) inches on passenger cars. Great care must be exercised to see that there is no snow under the shoes in making the adjustment. Brakemen must try the hand brakes on all the cars before trains leave these stations. Special attention must be paid to all rods and brake connections, brake shoes and

levers, key bolts and split keys, and to draft gear.

In making tests of brakes, engineers will give full pressure, and every effort must be made by inspectors and trainmen to locate and remedy defective or kinked hose, or any leaks in air pipes and connections.

4. Train and engine crews must know so far as lies in their power to do so, the exact condition of their brake apparatus on the entire train.

5. The engineer must also make an inspection of his air brake apparatus to see that it is in good condition; that the tender brakes are working properly, and that full pressure is obtained before starting. Where locomotives are equipped with water brakes, see that these, also, are in good working order.

6. Test of train must not be made from helper engine before it cuts off, but must be made from engine taking train down grade, unless the helper engine goes with the train.

7. After brakes have been released on passenger cars, and before trains start from these stations, retainers must be turned up.

8. No train will be allowed to leave these stations, until the engineer has been advised by the conductor in person that the train is ready to proceed.

9. Engineers must be advised by the conductors of the number of cars on which the air is not working; the number of cars in the train with air properly working; and the total number of cars in the train.

10. Trainmen must assist in holding freight trains with the hand brakes; hand brakes on as many cars as necessary to be set to act as retainers in case of air failure. Usually hand brakes should be set on cars at or near the head end of the train.

11. Trainmen must assist in holding passenger trains with hand brakes on cars where the retaining valves are not in proper working order; or other cars in either freight or passenger trains, if found necessary, in order to keep train under perfect control, and be ready to stop the train should the air fail.

11. The nailing, or use of nails in hose for the purpose of preventing

leakage to air brake couplings, should not be practiced, but new hose should be applied.

12. At least one member of the train crew must be on the rear end of the train in both ascending and descending grades, and a close observance of train made for sliding wheels.

13. Engineers must use every precaution against the parting of trains on heavy grades, and the train must be stopped at the first signs of parting, where it is possible for the train crew to do so, and report made of same.

14. In the handling of freight trains down Keystone hill and the north side of Dallas Divide, but one (1) car having non-air or inoperative air brakes will be permitted to descend in solid coal or ore trains, and not more than two (2) cars with non-air or inoperative air brakes in merchandise or mixed trains.

15. In case of breaking in two, or any other cause for train line being parted on grades, trainmen will before starting or moving train notify engineers before releasing hand brakes and will test the air as explained in Art. No. 3.

16. Conductors and brakemen in addition to inspecting their train at certain designated points on the line will also take advantage of any stop they make to thoroughly inspect train to ascertain whether or not running gear and brake appliances are in good condition.

17. Rio Grande Southern employees will be governed by General Rules and Regulations in effect on the Denver and Rio Grande Railroad.

18. AIR BRAKES.—The air-hose, when not coupled between cars, must be coupled to dummy coupling provided for that purpose. (See Question No. 1, Air-Brake Instructions.) Air-brakes must be tested on trains before leaving terminal stations, as required by Air-Brake Instructions. When double-heads are run, the air must be coupled to both engines, and forward engine man must operate the air-brake. Pushing engines must always have air-brake coupled.

19. Passengers will not be carried on freight trains.

F. E. PEAKE,

Chief Dispatcher.